

The Spinder 'Cosmos' free stall divider is a prime example of an 'open' cubicle. Large and spacious: therefore very animal friendly. This open system provides room enough for the cow to move naturally, when getting up and laying down. Consequentially the cows will lay down sooner which will improve production and hoof health.


For matting we advise a cow mattress: the Spinder Meadow mattress or the waterbeds. The combination Cosmos and loose bedding is also a possibility.

The PE retaining knee rail ensures for a perfect position of the animal, resulting in clean cows and cubicles.

## Major characteristics:


- Exceptionally 'open' cubicle which allows the cow to move naturally, when getting up and laying down;
- Plenty head space;
- Simple and solid design;
- Neck rail: 120 cm;
- Widely applicable;
- Easy to install and adjust;
- Flexible and adjustable knee rail;


01.15.500	Freestall divider model 'Cosmos'
	(mounting support piece and T-clamp included)
	<b></b>
44 44 240	Fittings
11.11.240	Floor anchor M12 x 106 (4 per divider)
10.20.600	Tube 60 mm, length 6 m
04.21.020	Tube clamp coupling 60mm
04.24.020	End coupling 60 mm
11.06.200 01.15.550	Stopper 60 mm Knee rail attachment PE125
01.15.550	
01.15.560	for 'Cosmos', adjustable (1 per divider) PE125 knee rail, length 1.00 Mtr.
01.15.560	(stall width 110-115 cm)
01.15.561	PE125 knee rail, length 1.07 Mtr.
01.15.501	(stall width from 115 cm)
01.15.565	PE125 knee rail, length 1.25 Mtr.
01.15.505	(last knee rail, from divider to end wall)
01.90.370	End coupling for knee rail PE125
01.30.370	(attachment knee rail at end wall)
11.11.210	Floor anchor M10 x 71 mm
	(2 per end coupling)
01.15.590	Ouick release for Cosmos
	<b>(</b>
	Model 'Cosmos' with head rail and neck rail
01.15.525	Connection for head rail four-way clamp incl.
	(1 per divider)
1	•











• Quick release for easy backdriving cow

